Paramétrage du scanner de code-barre Zebra DS2208 pour utilisation avec AlmaPro

DS2208

Table des matières

Téléchargement de l'utilitaire 123Scan 1
Mise à jour du logiciel du scanner de code-barre 2
Configuration du scanner de code-barre dans 123Scan 4

Téléchargement de l'utilitaire 123Scan

Cliquez sur le lien pour télécharger l'utilitaire 123Scan :

https://www.zebra.com/fr/fr/support-downloads/software/scanner-software/123scan-utility.html

Cliquez ici :



Puis, sélectionnez l'installateur pour Windows 64 bits :



L'installation est simple, il suffit de cliquer quelques fois sur « Suivant » et « Terminer ».

Mise à jour du logiciel du scanner de code-barre






Upgrade firmware and reset to factory default
Confirm you want scanner settings restored to factory defaults.
BACK
CONTINUE


Update firmware
Confirm that you want to update the following scanner
DS2208-COMMON SR MODELS
Serial number: 22116010552663
Existing: Release 017 - 2022.10.11 (CAADES00-005-R00)
Update to: Release 017 - 2022.10.11 (CAADES00-005-R00)
Step 3 - Rebooting scanner, please wait...
Do NOT disconnect scanner.
Update firmware
DISCOVERED SCANNER LIST
CLOSE


Update firmware
Confirm that you want to update the following scanner
DS2208-COMMON SR MODELS
Serial number: 22116010552663
Existing: Release 017 - 2022.10.11 (CAADES00-005-R00)
Update to: Release 017 - 2022.10.11 (CAADES00-005-R00)
Upload complete
100 %
It is now safe to disconnect the scanner.
Update firmware
DISCOVERED SCANNER LIST
UPDATE ANOTHER
CLOSE

Configuration du scanner de code-barre dans 123Scan






123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
Factory Default
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
1. Name and notes
Name:Factory Default
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General
Factory default settings
7. Printing Options
8. Load and print
Name and notes
Please be sure to give your settings a configuration name. You can also add notes and give the configuration name a version number.
Configuration name:
AlmaPro
What is this?
16 character limit
Notes:
500 of 500 characters remaining
< Back
Next >
Done
Cancel
Search for a parameter...


123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
AlmaPro
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
Name:AlmaPro
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General
Factory default settings
7. Printing Options
8. Load and print
^ Parameters changed from factory default
What cable are you using to connect your scanner?
Your scanner is already set up to communicate to your host using the most common communication protocols
You can use the tab(s) below to setup / modify up to 4 cable types (communication protocols) on your scanner.
USB
Keyboard Wedge
IBM-RS485
add cable
Basic Settings
USB Device Type
HID Keyboard Emulation
Ignore Unknown Characters
Send Bar Code with Unknown
Do Not Send Bar Code with Unknown
IBM Handheld / Tabletop / OPOS Options
HID Keyboard Options
SNAPI Options
CDC Options
< Back
Next >
Done
Cancel
Search for a parameter...


123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
AlmaPro
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
Name:AlmaPro
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General
Factory default settings
7. Printing Options
8. Load and print
^ Parameters changed from factory default
Change your bar code settings
Disable all symbologies | Print sample bar codes
Your scanner is already set up to recognize the most common types of bar codes. To modify your decoding options, select a symbology (bar code type) from the drop-down below.
DataMatrix
Data Matrix
Data Matrix Inverse
Inverse Autodetect
GS1-Datamatrix
< Back
Next >
Done
Cancel
Search for a parameter...


123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
AlmaPro
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
Name:AlmaPro
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General
Factory default settings
7. Printing Options
8. Load and print
^ Parameters changed from factory default
Modify Data
If required, create a data formatting rule to modify scanned data before its transmission to the host.
Send data as scanned, don't append any keystrokes. (Factory Default).
Append an enter key: Adds an Enter key to the end of scanned data.
Append a tab key: Adds a Tab key to the end of scanned data.
Program complex data modifications or select a rule from your Data Formatting Library.
< Back
Next >
Done
Cancel
Search for a parameter...


123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
AlmaPro
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
Name:AlmaPro
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General
Factory default settings
7. Printing Options
8. Load and print
^ Parameters changed from factory default
Change image settings
The parameters below pertain to imaging settings.
Click on blue links below for faster parameter list navigation.
Signature Capture
Signature Capture
Signature
Signature Capture File Format
JPEG
Signature Capture Bits Per Pixel
8 BPP
Signature Capture Width
400
Signature Capture Height
100
Signature Capture JPEG Quality
65
< Back
Next >
Done
Cancel
Search for a parameter...


123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
AlmaPro
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
Name:AlmaPro
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General
Factory default settings
7. Printing Options
8. Load and print
^ Parameters changed from factory default
General
The parameters below are general scanner settings and user preferences.
Click on blue links below for faster parameter list navigation.
Power
System
Beeper
Power
Power Mode
Continuous On
Time Delay To Low Power
1 Hour
System
Parameter Scanning Allowed
Keyboard Country Type ^
French (France)
Country Code Page
Default for a set Country Type
Unicode Output Control
Universal Output
< Back
Next >
Done
Cancel
Search for a parameter...

Si vous souhaitez supprimer les bips du scanner, vous pouvez indiquer les paramètres ci-dessous :






123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
AlmaPro
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
1. Name and notes
Name:AlmaPro
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General ^
Custom settings
7. Printing Options
8. Load and print
Printing Options
The parameters below are print and paper options
Default Options
Page Setup
Barcode Layout
Parameter Scanning
Default Options
Start programming barcode with
No Defaults
Set Factory Defaults
Set Defaults
Print only parameters changed from defaults
Erase All Rules
Page Setup
Paper Size
Letter (8.5 x 11.0 in, 216 x 280 mm)
Orientation
Portrait
Landscape
Margin Top
100
x0.01 Inches
< Back
Next >
Done
Cancel
Search for a parameter...


123Scan
Barcodes
Preferences
Tools
Help
Start
Data view
AlmaPro
Actions
Save file to PC
Print bar code
Load to scanner
Email Bar Code to Phone
Print/Save parameters
How to video
Model List
Plug-in Name
Release Notes
App Developer Report
DS2208-COMMON SR MODELS-017
Name:AlmaPro
Notes:
2. Cable connection
USB (default)
Keyboard Wedge
IBM-RS485
3. Symbologies (bar code types)
Factory default settings
4. Modify Data
No rules
5. Imaging
Factory default settings
6. General ^
Custom settings
7. Printing Options
8. Load and print
^ Parameters changed from factory default
Load and print
Choose from the options below to program your scanner
Save to PC
Print bar code
Load to scanner
Email bar code to phone
Email electronic config file
Print/export parameter report
< Back
Next >
Done
Cancel
Search for a parameter...

Load configuration
DS2208-COMMON SR MODELS
Firmware version: Release 017 - 2022.10.11 (CAADES00-005-R00)
DS2208
model list
1 compatible scanner(s) found for your configuration.
LOAD TO ALL SCANNERS
Refresh scanner list
22116010552663 - CAADES00-005-R00
If you do not see your scanner listed print the bar code and scan it to confirm the scanner is properly communicating over USB.
Clicking on a scanner above will begin the loading for that scanner. You can click the FLASH/BEEP icon within a row to find that particular scanner. Or to initiate the loading of all scanners, click the LOAD TO ALL SCANNERS button above.
DISCOVERED SCANNER LIST
CLOSE


Load configuration
DS2208-COMMON SR MODELS
Firmware version: Release 017 - 2022.10.11 (CAADES00-005-R00)
DS2208
model list
1 compatible scanner(s) found for your configuration.
LOAD TO ALL SCANNERS
Uploading AlmaPro
1 of 1 scanner(s)
42 %
DISCOVERED SCANNER LIST
CLOSE


Load configuration
DS2208-COMMON SR MODELS
Firmware version: Release 017 - 2022.10.11 (CAADES00-005-R00)
DS2208
model list
1 compatible scanner(s) found for your configuration.
LOAD TO ALL SCANNERS
Upload complete.
1 of 1 scanner(s)
100 %
LOAD MORE
DISCOVERED SCANNER LIST
CLOSE